Enercon Systems Pvt. Limited

Reg.Off: 179 - 180, Jain Colony, In Front Of Shiv City, Rau Indore – 452 012 (M.P.) Ph: +91 99779 87851, Email: espl@enercon.net.in, Website: www.enercon.net.in



Body Up Indicator

Model – BUI 01

Mfgd.as per DGMS
Guidelines

(Tub High Indicator / Canopy Up Alarm)

Operator of H.E.M.M., while operation, doesn't know the position of the dump body, whether it is in high or low position. If dumper moves in body lift position, overhead HT lines may break or hydraulic system may collide and cause fatal accident. Therefore in order to indicate that the body isin lifted position, Director General Mines & Safety vide circular No 5 of 2010 have instructed to install Body Up Indicator in every vehicle.

To avoid accident, We have developed an electronic safety device called "BODY UP INDICATOR" which gives indication to the operator and also alert in Beep sound.

Salient Features of Body Up Indicator –

1. Controller Unit: A Microcontroller unit is installed in the cabin of the dumper. When it receive signal from sensor about lifting of body, it gives information to the dumper operator in Beep Sound & Indication is also made through bright LED. Controller unit is installed in such a way that driver can see LED and hear the Voice clearly. The reset button is also provided on the controllingunit to mute the voice, but LED indication will continue till the body return back into normal (Rest)position.



- **2. Sensor :** Non contact Magnetic sensors are used to sense the body position. These sensors are Water Proof, Dust Proof, Vibration Proof and made to use in mining environment. It is installed in such a way that whenbody is in normal (rest) position, it will sense its position through magneticsensor and continue to send signal to the controller unit. There is no mechanical contact between the body and sensor therefore the life of the sensor is very high.
- **3. Harness**: A good quality harness suitable for system to connect Controller Unit & Sensor is available as optional.

Advantages of using Body Up Indicator -

- 1) When body is in high position and the dumper moves, it may break the overhead HT line and cause fatal accident. To avoid this situation, Body Up Indicator alerts the operator.
- 2) When body is in high position, it exerts heavy pressure on hydraulic system and if dumper moves, hydraulic system may fail. The dumper operator when listen the Voice Sound, he understands that body is in up position and takes all necessary precautions to avoid accident.

AUDIO ALERT	85 dB " VOICE" Alert Sound (डाला ऊपर हैं)
CONTROLLER UNIT	Input voltage 12 To 24 ± 2 V.DC
SENSOR	To protect from dust & moisture, Sensor is sealed with chemicals.